



ORDER BY PART NUMBER, NOT CODE NUMBER

CODE NO.	PART NO.	NO. REQ.	DESCRIPTION	CODE NO.	PART NO.	NO. REQ.	DESCRIPTION
1	IP1876	1	Stopper Assembly (Includes Codes 2-6)	30	IP71022	1	Rotating Shredder Assy
2	IP1875	1	Stopper, Handle	31	IP14140	1	Upper End Bell Assy (Incl. Code 36)
3	IP1144	1	Gasket, Stopper (Inner)	32	IP1470	1	Gasket, Tailpipe
4	IP5015C	1	Gasket, Body	33	IP70076	1	Tailpipe
5	IP5045	1	Ring, Retaining	34	IP5490	1	Flange, Tailpipe
6	IP5029	1	Gasket, Stopper (Outer)	35	IP1491	1	Screw, Tailpipe
7	IP10025B	1	Flange, Strainer	36	IPS14148	1	Insulation, UEB
8	IP8763	2	Seal, Sink Flange	37	IPS13691B	1	Cover, Trim Bottom
9	IP1160	1	Gasket, Sink Flange	38	IPS14151A	1	Stator Assembly
10	IP5150E	1	Flange, Backup	39	IPS14138	1	Rotor & Shaft Assembly (Incl. Codes 40)
11	IP5141	1	Flange, Mounting	40	IP2642	1	Washer
12	IP5147	3	Screw, Backup	41	IP2467A	1	Switch Centrifugal
13	IP5166	1	Ring, Retaining	42	IP4134	1	Shield Wire
14	IP1010A	1	Gasket, Mounting	43	IP70360A	1	Switch, Start Reverse
15	IP5298	1	Flange, Body	44	IPS13734	1	Protector, Overload
16	IPS2567A	1	Trim Cover, Top	45	IPS13579	1	Capacitor
17	IP14128	1	Trim Shell Assembly	46	IP71425	1	Clip Capacitor
18	IPS8320	1	Insulation	47	IP70424	1	Lower End Frame Assembly
19	IP9872G	1	Body Container Assembly (Incl. Codes 21 & 22)	48	IP9121A	4	Screw, #10-24 Pan Hd
20	IP71788	3	Screw, Body Container	49	IP70999	1	Screw, Ground
21	IP8797	1	Clamping Ring	50	IP71387	1	Terminal Cover
22	IP4395	1	Gasket, Shredder	51	IP70734	1	Screw, Terminal Cover
23	IP1248A	1	Shredder, Stationary	52	IP70440A	1	Cord Assembly
24	IP70647	1	Sleeve & Seal Kit (Incl. Codes 25-29)	53	IP70667	1	Bushing
25	IP2854	1	Plug	54	IP2610TE	1	Instruction Assy (Not Shown) (Incl. Codes 8, 32-35 & 55)
26	N/A	1	Bolt, Hex Head Flange	55	IP10097B	1	Installation, Use & Care Booklet (Not Shown)
27	N/A	1	Slinger				
28	N/A	1	Seal				
29	N/A	1	Sleeve				